


EASY SETUP GUIDE

*****STEP 1*****

1. Make sure your 8100 service has been activated with LandAirSea. Your unit came with an activation sheet or you can download it from www.landairsea.com. Fill it out and fax it to the number that is on the sheet. Wait for an e-mail response from LandAirSea with your Unit Number. Also be sure to fax the completed Customer Agreement sheet as well.
2. Powering up your 8100 for the first time. Turn your 8100 on and watch the second LED (#2). It should be flashing red/green. Wait for it to flash just green. Now turn the 8100 off and then back on. LED #2 should now flash red once per second. If LED #2 does not flash once per second, please contact LandAirSea support. **WARNING** – A rapid red flashing on LED#2 means that your unit did not activate.
3. Initialize the GPS. Take your 8100 unit outside so that it has a clear view of the sky and wait for the GPS light (LED 4) to flash once per second. You are ready for Easy Setup Guide - Step 2.



For more detailed software instructions, download the full User's Guide in the LandAirSea 8100 downloads section of the LandAirSea Downloads web page.

EASY SETUP GUIDE

*****STEP 2*****

1. Install Google Earth. Download the setup program for the Google Earth application by going to the webpage: earth.google.com. Run the Google Earth application. Go to Tools, then Options. Click on the Touring tab. Change the Fly-To Speed to 0.5. Then click Ok. You can minimize or exit Google Earth.
2. Install UTW – Universal Tracking Wireless. Download the LandAirSea 8100 application (UTW) from the Support/Downloads page on the LandAirSea Website (www.landairsea.com). The name of the software needed is called Universal Tracking Wireless or UTW. After you download and run the setup program, there will be an icon on your desktop called UTWireless Client (UTW).
3. Run the UTW program. You will be asked to create a User database. Click on the Setup Users button from the Setup Tab. Fill out the information in the New User section. Your Unit Number will be e-mailed to you upon activation. Name is what you want to call the vehicle (ex:John). Password is the password you used on put on your activation sheet. Select the package you chose, Plan 1 is the 1 Mb. Plan 2 is the 3 Mb, and Plan 3 is the Unlimited. Leave Group box blank unless you have more than 10 units. Click on the Add button, then Ok. You will be asked to exit the program. Make sure you select Yes and then restart the program.

For more detailed software instructions, download the full User's Guide in the LandAirSea 8100 downloads section of the LandAirSea Downloads web page.

EASY SETUP GUIDE

*****STEP 3*****

1. Send a command to track your 8100. In the UTW program, go to the Users/Commands tab and select the vehicle by pushing in the button that has the description of your vehicle. Google Earth will automatically open. Select how often you want the tracking unit to update it's location (1 sec, 2 sec, 5 min. etc.). Then click the send button. **YOU ONLY NEED TO CLICK THE SEND BUTTON ONE TIME.** Unless you send a Stop command, your tracking unit will remember the tracking setting indefinitely even if you turn the power off.
2. Go to the Controls tab and make sure the pause button is solid (not flashing).
3. Have someone you know place the 8100 in a car (preferably on the dashboard for this test) and take about a 10 minute test drive while you watch the computer screen. Within a few minutes, you should see the location of your vehicle on Google Earth. **DO NOT SELECT ANY OPTIONS OR CLICK ON ANY OF THE CONTROLS WITHIN GOOGLE EARTH.** The LandAirSea UTW application controls Google Earth. If you are done tracking the vehicle, you can either exit the program or click the pause button and minimize the applications.

For more detailed software instructions, download the full User's Guide in the LandAirSea 8100 downloads section of the LandAirSea Downloads web page.